

## CARE AND USE INSTRUCTIONS

Thank you for selecting a WeatherBeater<sup>TM</sup> Floor Liner from Winfield Consumer Products. Your new third seat liner is custom molded to fit your vehicle with 2<sup>nd</sup> row bucket seating. The liner is made to take the place of your factory floor mats. *For correct fit, it is necessary to remove the factory floor mats before installing your new floor liner*. However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409<sup>®</sup> or Glass Plus<sup>®</sup> work well. Use of Armor All<sup>®</sup>, Son-of-a-Gun<sup>®</sup> or similar items is discouraged as these products make the liner slick.

## INSTALLATION INSTRUCTIONS FOR YOUR BUICK ENCLAVE AND CHEVROLET TRAVERSE THIRD SEAT FLOOR LINER (VEHICLES WITH 2<sup>ND</sup> ROW BENCH SEATS)



TO EASE INSTALLATION OF YOUR LINER, FLIP FORWARD / FOLD THE  $2^{ND}$  ROW SEATS TO EXPOSE THE  $3^{RD}$  ROW FLOOR. NEXT, INSTALL YOUR LINER, POSITIONING IT AS SHOWN ABOVE. LASTLY, REPOSITION THE  $2^{ND}$  ROW SEATS AS DESIRED.