



# UNI-FIT FLOOR MATS

## CARE AND USE INSTRUCTIONS - PN: 51509 Front & Rear Mat Set

Thank you for selecting UNI-FIT™ Floor Mats from Husky Liners Inc. Your new floor mats can be easily trimmed to fit your specific vehicle's floorboard. The mats are made to take the place of your factory floor mats. ***For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners. However, do not remove the factory-installed carpeting.***

Your mats are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your mats is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.

LEFT OR DRIVER

RIGHT OR PASSENGER

FRONT SEAT



REAR





# UNI-FIT FLOOR MATS

## CARE AND USE INSTRUCTIONS - PN: 51509 Front & Rear Mat Set

---



Trim and discard the formed tab at the top of the floor mats using a pair of scissors or a utility knife.

---

**Pre-fit your** UNI-FIT mats in your vehicle to determine if trimming is necessary. If trimming is needed, the mats can be easily trimmed with a pair of scissors or a utility knife.



**Use the molded in grooves to guide trimming.**